


Commercial Gas Water Heaters



How to Locate the Mercury Flame Sensor

- ① Look for a 3-prong male connector plugged to the gas valve.
- ② Trace the capillary tube from the connector to the mercury sensor probe attached to the pilot light assembly.
- ③ To remove the mercury flame sensor, unplug it from the gas valve and detach it from the pilot light assembly.

Not all commercial gas water heaters have mercury flame sensors. See Poster #9.

