



# How to Remove Mercury Switches in Hood and Trunk Lights



Hood light



Trunk light

## GM (General Motors)



1 Remove the light bulb.



2 Remove the C-clip from the black plastic housing.



3 Push the housing through the metal brace.



4 Remove the spring.



5 Pry the housing in half to get the mercury switch.



1 Remove the light bulb.



2 Remove the C-clip from the black plastic housing.



3 Push the housing through the metal brace. Remove the spring.



4 Pry the housing in half to remove the mercury switch.



1 Remove the light bulb.



2 Snap off the metal brace and pry the light assembly apart.



3 Remove the mercury switch.



1 Remove the clear plastic dome.



2 Pry the mercury switch from its brace.

